Ground spring needle assembly

1



Align the hole on the 3,5mm GND towards the needle

2



Press and twist on the 3,5mm GND on the metal cylinder.
Please be aware of the sharp needle tip!